

ACQUAPURO

Filter Replacement Instructions

1. Locate the isolation valve on the inlet side of the pipework to the filter. If there isn't one you will need to isolate the main incoming cold water supply.
2. Remove your existing filter and filter bracket and screw the Acquapuro snap fit bracket into the same position with the wood screw provided.
3. Push the filter into the bracket until clicks into place.
4. Remove the ¼" plastic pipework from your existing filter. The diagram below shows how this is achieved but it might not resemble your actual filter. Push the small collar (A) towards the tee/filter/adaptor while pulling the white plastic pipe (B) at the same time. Please be aware that there is water in the white plastic pipework so be prepared for a little to dribble out.
5. Connect the push fit pipework to the new filter by simply pushing it in to the elbow as far as it will go, now click the filter in the mounting bracket. Make sure the correct hose is attached to the correct elbow. The left-hand elbow in the image below is the inlet. We suggest making a note a calendar or similar for six months, as this will be when the replacement is required.
6. Turn the isolation valve or mains incoming water supply back on to allow the water to flow through the replacement filter. Allow the water to flow for 1 minute.
7. The installation is now complete; we recommend the pipework connections to the filter are double-checked after a few hours to ensure there are no slow leaks.

